



NOTES: UNLESS OTHERWISE SPECIFIED:
 1) ALL RESISTOR VALUES ARE IN OHMS, Ω , $\%$.
 2) ALL CAPACITOR VALUES ARE IN MICROFARADS/VOLTS.
 3) ALL DIODES ARE INAC40.
 4) ALL COMPONENTS SO NOTED ARE OPTIONAL.

5) WHEN JH-41 L/M SYSTEM IS USED REPLACE R800 WITH A JUMPER.
 6) WHEN MUTE AMP IS PC400-DAT-100 IS USED, REMOVE JUMPER BETWEEN J105 AND J106.

AND - FRS. IN ADDITION, REMOVE RELAYS R2, R5 AND R500. COMPONENTS JUMPER WITH R2 AND R5 CONTACTS OF R5.